



CT800 TREADMILL



Optional Extended Handrails



Optional TV Bracket (TV not included)

The CT800 is stout and extremely durable, weighing in at over 350 lbs. The combination of the heavy-duty steel frame and aluminum console masts and side rails make it comparable to treadmills at much higher price points in the commercial market. The large workout area makes this model very appealing to walkers and runners.

CT800 TREADMILL

- Bright, tri-color LED console with programming very similar to our other C series consoles
- Quick speed and incline keys to save time and make workouts more efficient
- Contact and wireless heart rate options to help keep clients in their safe and effective training zone
- Dual-drive motor cooling fans to protect and extend the life of the motor and control board
- Maintenance free, hard wax deck system provides hassle free use for thousands of miles
- Spacious 22" x 60" workout area to accommodate tall individuals
- Multi-ply Habasit® commercial belt for superior belt life
- C-safe power and communication capabilities for A/V control



Fan to keep you cool

Large, blue LED matrix window

Tablet friendly reading rack holder

Heart rate percentage profile

Quick speed and incline buttons

Convenient water bottle holder and cargo compartment

Ergonomically correct contact heart rate grips

CT800 CONSOLE FEATURES

As with any product, a major importance is the user interface. We focused on making everything easily accessible and comfortable: dual storage trays for beverages, keys, or phone, ergonomically friendly pulse grip posts for a more natural hand position, and a turbo cooling fan to keep your clients cool and encourage them to work out longer. Our large, easy-to-read console gives them constant feedback from calories to distance to time.

EQUIPMENT SPECIFICATIONS

Console	large blue LED matrix with 4 separate LED info windows, 20-character LED message center, LED heart rate bar, C-safe compatible, tablet friendly reading rack
Programs	manual, interval, 5k, hill, fat burn, cardio, fit test, Gerkin Protocol Fit Test, 4 military readiness tests (Army, Navy, Air Force, Marines), 2 HR, custom
Heart Rate	contact and telemetric compatible (chest strap sold separately)
Speed/Incline	0.5 – 12 mph / 5 – 15%
Power	120 volts (NEMA 5-15P electrical cord); 15-amp circuit recommended
Drive Motor	4.0 HP DC drive with grade H insulation
Deck	1" phenolic, double-sided, wax-coated
Belt	22" x 60", Habasit® commercial, multi-ply
Rollers	3.0"
Frame	heavy-gauge high-strength steel with durable powder-coat paint, aluminum masts and side rails
Dimensions	84" x 35" x 57"
Product Weight	353 lbs.
Max User Weight	450 lbs.

WARRANTY INFORMATION

Commercial Warranty (Non-dues Paying Facilities) – Lifetime frame, 5 years motor, deck and parts, and 2 years labor