



# XT685 TREADMILL



The XT685 offers a large workout area with a 22" x 60" belt. The 3" crowned rollers allow for a lower tension system, which creates less heat and stress making for more reliable, longer-lasting system. Combine that with our 1" thick deck with hard wax system and you get a treadmill that will stand up to the many hours of use. With a long list of premium features that will delight your clients and weighing in at 269 lbs., the XT685 is a great option for your facility.

## **XT685** TREADMILL

- Oversized 9" bright blue backlit LCD screen with separate Muscle Activation Profile and HR % Profile LED displays
- Remote Handlebar Toggles for both speed and incline allow for secure workout changes without taking your hands off the side handlebars
- Contact and wireless heart rate monitoring options make your workouts more effective (chest strap transmitter included)
- Spacious 22" x 60" workout area with powerful 4.0HP motor and wax deck system
- Adjustable cooling fan and dual speakers with audio jack for comfort and entertainment
- Quick Speed and Incline keys to save time and make workouts more efficient



## XT685 CONSOLE FEATURES

As with any product, a major importance is the user interface. We focused on making everything easily accessible and comfortable: dual storage trays, handlebar mounted speed and incline toggles, ergonomically friendly pulse grips, adjustable cooling fan and integrated speakers with audio jack to keep you encouraged to work out longer.

A quick press of a button and you are off on a walk, a run, or one of the many specialized work outs. Our large, easy-to-read console gives you constant feedback on all areas of your workout.

### EQUIPMENT SPECIFICATIONS

<b>Console</b>	9" blue backlit LCD, heart rate % profile, muscle activation profile, tablet friendly reading rack, adjustable fan, speakers w/3.5mm audio jack
<b>Programs</b>	manual, hill, fat burn, cardio, strength, interval, calories, fusion, user 1-2, HR 1-2
<b>Heart Rate</b>	contact and telemetric (heart rate transmitter strap included)
<b>Speed/Incline</b>	0.5 - 12 mph / 15 levels
<b>Handlebar Toggles</b>	speed and incline
<b>Drive Motor</b>	4.0 HP
<b>Deck</b>	1" waxed deck
<b>Belt</b>	22" x 60"
<b>Rollers</b>	3.0" (crowned)
<b>Frame</b>	heavy-gauge high strength with durable powder coat paint
<b>Dimensions</b>	78" x 32" x 56"
<b>Product Weight</b>	269 lbs.
<b>Max User Weight</b>	425 lbs.

### WARRANTY INFORMATION

**Commercial (Non-Dues Paying Facilities):** Lifetime frame, 5 years motor, 3 years deck and parts, and 1 year labor