



FREECLIMBER 8FC

The 8 series FreeClimber™ builds on our 30-year reputation of performance and comfort to offer the most innovative climber experience in the gym. The FreeClimber™ step design includes added cushion and independent pedal geometry, with four-bar linkage to create a fluid, natural stepping motion. With three smart OpenHub™ console options that offer solutions for all of your entertainment, fitness tracking and asset management needs. It's the combination of quality and innovation that provides users with the machines that make hearts pound, lungs burn and keep members coming back to the workouts they love to hate.



STEP RIGHT

Electronically controlled alternator with chain drive precisely controls the pedal descent allowing a wide range of users to exercise smoothly within their comfort zones. Plus, patented independent pedal geometry with four-bar linkage keeps pedals level ensuring a comfortable, biomechanically correct movement



OPENHUB CONSOLES

Choose between 10", 15" & LCD versions of the new OpenHub family of consoles featuring 10 programs – Quick Start, Manual, Fat Burner, Calorie Burner, Speed Intervals, Custom Intervals, Random Intervals, Heart Rate Intervals, Calorie Goal, Heart Rate Zone Trainer



8-FC FREECLIMBER

BASE FEATURES

STEP SURFACE	Soft Trac Cushion
STEP HEIGHT	1 to 14in (2.5 to 36cm)
STEP RATE	24-174 steps per minute
STEP UP HEIGHT	N/A
HEART RATE MEASUREMENT SYSTEM	Telemetry and contact HR (Bluetooth with embedded display)
CONTROLS	Display
DISPLAY	Choose from LCD, 10" or 15" OpenHub display options
ACCESSORIES	Multiple bottle and accessory holders, LCD and 10" displays pre-wired for 8 Series PVS entertainment, 800/900MHz receivers, and tablet holder
MAX USER WEIGHT	350lb (159kg)
DRIVE SYSTEM	Alternator
ELECTRICAL REQUIREMENTS	LCD is self-generating: touch screen and PVS options require 12V/5 Amp power supply
ADDITIONAL FEATURES	Patented independent pedal geometry with four-bar linkage keeps pedals level ensuring a comfortable, biomechanically correct movement; Landmark Challenge

FRAME

MATERIAL	Powder Coated Steel Frame
CUSTOMIZABLE	Paint color options approval required
STANDARD COLOR OPTIONS	Matte Black (-60)
LENGTH	43in (110cm)
WIDTH	27in (69cm)
HEIGHT	68in (173cm)
PRODUCT WEIGHT	187lbs (85kg)
SHIPPING DIMENSIONS	46in x 30in x 44in (117cm x 76cm x 113cm)
SHIPPING WEIGHT	249lbs (113kg)

ADDITIONAL SKUS

9-5260-8FC-LCD-60BLK

9-5260-8FC-2019-15-ISDB-DMB-PAL-60BLK

9-5260-8FC-2019-15-ATSC-60BLK

9-5260-8FC-10-60BLK



CONSOLES

DISPLAY	15" StairMaster	LCD	10"
DISPLAY TYPE	Capacitive Touchscreen	Static LCD	Resistive Touchscreen
MULTI-LANGUAGE OPTIONS	English, German, Spanish, Dutch, Portuguese, French, Italian, Swedish, Russian, Finnish, Danish, Chinese, Japanese, Turkish, Polish, Russian, Hebrew, Czech, Slovak	English, German, Spanish, Dutch, Portuguese, French, Italian, Swedish, Katakana, Russian, Finnish	English, German, Spanish, Dutch, Portuguese, French, Swedish
PRE-PROGRAMMABLE WORK OUTS	Yes, 16+	Yes, 14+	Yes, 11+
QUICK START OPTIONS	Yes, single button start options	Yes, single button start options	Yes, single button start options
TV TUNER ENABLED	Yes (Global tuner options)	No	No
ETHERNET AND WIFI ENABLED	Yes	No	No
BLUETOOTH DATA TRACKING/APP CONNECTIVITY	Yes	Yes	Yes
BLUETOOTH HEADPHONES	Yes	No	No
BLUETOOTH HEART RATE	Yes	No	No
APPLE GYMKIT	Yes	Yes	No
RUNTV INTEGRATED WORKOUT VIDEOS	Yes	No	No
INTEGRATED WEB-BASED APPS	Yes	No	No
CUSTOMIZABLE HOME SCREEN	Yes	No	No
HDMI STREAMING	Yes; cables not included	Yes, HDMI streaming available with PVS option; cables not included	Yes, HDMI streaming available with PVS option; cables not included
USB	USB port for software updates and device charging; cables not included	USB port for software updates and device charging; cables not included	USB port for software updates and device charging; cables not included
RFID	Optional	No	No
IPTV/SET TOP BOX COMPATIBLE	Yes, add-on accessories required	Yes, with PVS	Yes, with PVS
ANT+ FOR GROUP DISPLAY	Yes	Yes	Yes
PERSONAL FAN	Yes, programmable auto start	Yes, programmable auto start	Yes, programmable auto start
ASSET MANAGEMENT	Ecofit Optional	Ecofit Optional	Ecofit Optional
TABLET HOLDER	Integrated front	Integrated front, optional top add-on	Integrated front, optional top add-on
PVS	No	Optional	Optional
800/900 MHZ RECEIVER	No	Optional	Optional



PVS FEATURES

PVS	10/8 Series
DISPLAY TYPE	15.6" HD LED
RESOLUTION	1366 x 768
TUNER OPTIONS	1) ATSC/NTSC/QAM 2) PAL/DVB-T/DVB-C 3) Pro:Idiom
DIGITAL AND ANALOG SUPPORT	Yes
SIGNAL INPUTS	Coax, HDMI
INPUT RF SIGNAL RANGE	-70 dBm(Min) ~ - 10 dBm(Max)
CLOSE CAPTION	Yes
HEADPHONE JACK	3.5mm on Display

SKUS	DESCRIPTION
700-0496-16	BLACK MYE PVS SCREEN, 2016, ATSC/NTSC TUNER w/QS 10TR MOUNT
700-0500-16	BLACK MYE PVS SCREEN, 2016, PAL TUNER w/ QS 10TR MOUNT
700-0523-16	MYE PRO:IDIOM PVS w/QS 10TR MOUNT
700-0386-60	BLACK MYE PVS SCREEN, 2016, ATSC/NTSC TUNER w/60BLK TR MOUNT
700-0390-60	BLACK MYE PVS SCREEN, 2016, ATSC/NTSC TUNER w/60BLK BCG MOUNT
700-0392-60	BLACK MYE PVS SCREEN, 2016, ATSC/NTSC TUNER w/60BLK FC MOUNT
700-0387-60	BLACK MYE PVS SCREEN, 2016, PAL TUNER w/60BLK TR MOUNT
700-0391-60	BLACK MYE PVS SCREEN, 2016, PAL TUNER w/60BLK BCG MOUNT
700-0393-60	BLACK MYE PVS SCREEN, 2016, PAL TUNER w/60BLK FC MOUNT
700-0520-60	MYE PRO:IDIOM PVS w/60BLK 8TR-TRX MOUNT
700-0521-60	MYE PRO:IDIOM PVS w/60BLK BCG MOUNT
700-0522-60	MYE PRO:IDIOM PVS w/60BLK FC MOUNT