



FREERUNNER™ 10TRX

The 10TRx FreeRunner creates a revolutionary feel for runners and walkers. HexDeck Technology creates an unprecedented cushion and responsiveness – lightweight walkers, heavyweight runners and everyone in between will experience initial cushion/flex at foot strike, along with an immediate response, returning support and energy for the push off.



HEXDECK TECHNOLOGY

Our HexDeck System features an aluminum deck supported by a proprietary, hexagonal polymer suspension system. The deck dissipates heat, keeping a cooler surface for the belt and reducing wear. The deck panel will last many times longer than MDF - only a thin phenolic layer needs replaced when worn, significantly reducing the labor and material long-term cost of ownership.



OPENHUB CONSOLE

The 19" Capacitive Touch OpenHub Console offers a premium user interface design, Star Trac 20 HIIT Programming, RunTV and web-based media access for news, entertainment and workout motivation. With standard features like HDMI streaming, Bluetooth connectivity and TV tuner options, this is a display that has something for every user.



10-TRX FREERUNNER

BASE FEATURES	
DECK SYSTEM	Reverible Aluminum deck with independently-replaceable phenolic sheet
RUNNING BELT SYSTEM	22in (55cm) wide belt
SIZE OF RUNNING SURFACE	60in x 22in (152cm x 55cm)
ABSORPTION SYSTEM	HexDeck aluminum deck supported by proprietary hexagonal suspension system provides a revolutionary combination of shock absorption + response
STEP UP HEIGHT	11in (28cm)
INCLINE RANGE	0-20% max incline
SPEED RANGE	0.5-15mph (0.5-24kmh)
HEART RATE MEASUREMENT SYSTEM	Telemetry and contact HR, Bluetooth w/19" display option
CENTER CONTROLS BAR	Easily accessible Hot Bar® is located closer to the user with one-finger speed and elevation controls, integrated stop button and contact heart rate grips
DISPLAY	Choose from LCD or 19" OpenHub display options
USER DETECT SYSTEM	Yes, programmable on/off
ACCESSORIES	Multiple bottle and accessory holders, LCD displays pre-wired for 8 Series PVS entertainment, 800/900MHz receivers, and tablet holder
MAX USER WEIGHT	500lb (227kg)
DRIVE SYSTEM	5 HP AC motor
ELECTRICAL REQUIREMENTS	110V/20 Amp dedicated circuit with NEMA 5-20 outlet; or 220V/15 Amp dedicated circuit with NEMA 6-15 outlet
ADDITIONAL FEATURES	3.5in rollers
FRAME	
MATERIAL	Powder Coated Steel Frame
CUSTOMIZABLE	Paint color options approval required
STANDARD COLOR OPTIONS	Quantum Silver
LENGTH	81in (207cm)
WIDTH	35in (88cm)
HEIGHT	60in (152cm)
PRODUCT WEIGHT	494lbs (224kg)
SHIPPING DIMENSIONS	89in x 36in x 29in (226cm x 90cm x 74cm)
SHIPPING WEIGHT	547lbs (248kg)
ADDITIONAL SKUS	

9-9271-10TRX-110-ATSC, 9-9271-10TRX-110-LCDQ, 9-9271-10TRX-110-ATSC, 9-9271-10TRX-110-LCDQ-HM, 9-9274-10TRX-220CE-19-ATSC, 9-9274-10TRX-220CE-19-PAL, 9-9274-10TRX-220CE-LCDQ-KM, 9-9274-10TRX-220CE-LCDQ



CONSOLES

DISPLAY	19" Star Trac	LCD
DISPLAY TYPE	Capacitive Touchscreen	Static LCD
MULTI-LANGUAGE OPTIONS	English, German, Spanish, Dutch, Portuguese, French, Italian, Swedish, Russian, Finnish, Danish, Chinese, Japanese, Turkish, Polish, Russian, Hebrew, Czech, Slovak	English, German, Spanish, Dutch, Portuguese, French, Italian, Swedish, Katakana, Russian, Finnish
PRE-PROGRAMMABLE WORK OUTS	Yes, 23+	Yes, 14+
QUICK START OPTIONS	Yes, single button start options	Yes, single button start options
TV TUNER ENABLED	Yes (Global Tuner Options)	No
ETHERNET AND WIFI ENABLED	Yes	No
BLUETOOTH DATA TRACKING/APP CONNECTIVITY	Yes	Yes
BLUETOOTH HEADPHONES	Yes	No
BLUETOOTH HEART RATE	Yes	No
APPLE GYMKIT/SAMSUNG GALAXY WATCH CONNECTIVITY	Yes	Yes
RUNTV INTEGRATED WORKOUT VIDEOS	Yes	No
EGYM COMPATIBLE	Yes	No
INTEGRATED WEB-BASED APPS	Yes	No
CUSTOMIZABLE HOME SCREEN	Yes	No
HDMI STREAMING	Yes; cables not included	Yes, HDMI streaming available with PVS option; cables not included
USB	USB port for software updates and device charging; cables not included	USB port for software updates and device charging; cables not included
RFID	Optional	No
IPTV/SET TOP BOX COMPATIBLE	Yes, add-on accessories required	Yes, with PVS
ANT+ FOR GROUP DISPLAY	Yes	Yes
PERSONAL FAN	Yes, programmable auto start	Yes, programmable auto start
ASSET MANAGEMENT	Ecofit Optional	Ecofit Optional
TABLET HOLDER	Integrated front	Integrated front, optional top add-on
PVS	No	Optional
800/900 MHZ RECEIVER	No	Optional



PVS FEATURES

PVS	10/8 Series
DISPLAY TYPE	15.6" HD LED
RESOLUTION	1366 x 768
TUNER OPTIONS	1) ATSC/NTSC/QAM 2) PAL/DVB-T/DVB-C 3) Pro:Idiom
DIGITAL AND ANALOG SUPPORT	Yes
SIGNAL INPUTS	Coax, HDMI
INPUT RF SIGNAL RANGE	-70 dBm(Min) ~ - 10 dBm(Max)
CLOSE CAPTION	Yes
HEADPHONE JACK	3.5mm on Display

SKUS	DESCRIPTION
700-0496-16	BLACK MYE PVS SCREEN, 2016, ATSC/NTSC TUNER w/QS 10TR MOUNT
700-0500-16	BLACK MYE PVS SCREEN, 2016, PAL TUNER w/ QS 10TR MOUNT
700-0523-16	MYE PRO:IDIOM PVS w/QS 10TR MOUNT
700-0386-60	BLACK MYE PVS SCREEN, 2016, ATSC/NTSC TUNER w/60BLK TR MOUNT
700-0390-60	BLACK MYE PVS SCREEN, 2016, ATSC/NTSC TUNER w/60BLK BCG MOUNT
700-0392-60	BLACK MYE PVS SCREEN, 2016, ATSC/NTSC TUNER w/60BLK FC MOUNT
700-0387-60	BLACK MYE PVS SCREEN, 2016, PAL TUNER w/60BLK TR MOUNT
700-0391-60	BLACK MYE PVS SCREEN, 2016, PAL TUNER w/60BLK BCG MOUNT
700-0393-60	BLACK MYE PVS SCREEN, 2016, PAL TUNER w/60BLK FC MOUNT
700-0520-60	MYE PRO:IDIOM PVS w/60BLK 8TR-TRX MOUNT
700-0521-60	MYE PRO:IDIOM PVS w/60BLK BCG MOUNT
700-0522-60	MYE PRO:IDIOM PVS w/60BLK FC MOUNT