

# CE900

## ELLIPTICAL TRAINER



Workout comfort and performance were top of mind when the CE900 Elliptical was developed. From stride length and hand grips to pedal placement and flywheel inertia, this elliptical combines fit and function in one robust machine. With an outstanding warranty, owners can feel secure they've made a solid investment in their users' experience and their bottom line.

### FEATURES

- 30 lbs. flywheel with a 12:1 pedal to flywheel ratio creates the perfect balance for smooth stride motion at any speed/resistance level
- Extra wide, 12 groove poly-v belt with roller bearing tensioner system to provide smooth feel and long product life
- 21" stride length with 2-degree pedal inversion to assure a comfortable motion
- Industrial grade 72mm roller bearings assure for long life and added reliability
- Generator system allows the unit to be placed in any location



# CE900

## EQUIPMENT SPECIFICATIONS

<b>Console</b>	White multi-window LED displays (18-character message center, profile matrix, RPM, and level), cooling fan, USB charging port, Bluetooth FTMS (connects to fitness apps), water bottle holder
<b>Programs</b>	Manual, hill, fat burn, HR, HIIT, cardio, interval, watts, strength
<b>Heart Rate</b>	Contact and 5KHz (chest strap sold separately)
<b>Stride Length</b>	21"
<b>Resistance</b>	40 levels
<b>Power</b>	Self-generating
<b>Flywheel System</b>	30 lb with 12:1 pedal to flywheel ratio
<b>Pedals</b>	Oversized with 2-degree inversion
<b>Storage</b>	Reading rack
<b>Frame</b>	Epoxy hybrid, double powder coated, heavy gauge high strength steel
<b>Dimensions</b>	77" L x 32" W x 67" H
<b>Product Weight</b>	396 lb
<b>Max User Weight</b>	450 lb

## WARRANTY INFORMATION

**Commercial Warranty** – 10 years frame, 5 years brake, 3 years parts and labor, and 6 months wear items

\*Prisons and correctional facilities are excluded from warranty coverage.