

CU900 UPRIGHT BIKE



Easy Seat Adjustment

The CU900 Upright Bike boasts features that provide users with precise fit and function and a beautiful console to track performance. The seat height securely locks and adjusts at infinite increments while the molded handlebars provide ultimate comfort. Pedal motion is smooth and consistent with industrial roller bearings and 1" crank axle that can power through any climb.

FEATURES

- Extra wide, 8 groove poly-v belt, spring loaded idler for reduced belt tension for longer belt and bearing life
- Oversized 1" crank axle along with heavy duty roller bearings provide long life and reliability
- Quick adjust seat easily slides to accommodates users of various heights
- Easy in and out ratcheting pedals with 2-degree pedal inversion for a comfortable workout
- Generator system allows the unit to be placed in any location



CU900

EQUIPMENT SPECIFICATIONS

Console	Premium, ultra-bright white LED display with built in fan, integrated reading rack, with C-Safe port and power port for TV remote, heart rate graph bar
Programs	Manual, hill, fat burn, heart rate, HIIT, cardio, interval, watts, fitness test
Heart Rate	Contact, 5KHz (chest strap sold separately)
Resistance	40 levels
Drive Train	Extra wide, 8 groove poly-v belt with spring loaded idler
Power	Self-generating
Flywheel System	30 lb with 9.5:1 pedal to flywheel ratio
Pedals	Ratcheting pedals with 2-degree inversion
Storage	Reading rack, dual water bottle holders
Frame	Epoxy hybrid, double powder coated, heavy gauge high strength steel
Dimensions	48" L x 25" W x 55" H
Product Weight	143 lb
Max User Weight	450 lb

WARRANTY INFORMATION

Commercial Warranty – 10 years frame, 5 years brake, 3 years parts and labor, and 6 months wear items

*Prisons and correctional facilities are excluded from warranty coverage.